



Address:
JAMBU PERSHAD & SONS
6275/22 Nicholson Road,
Ambala Cantt, Haryana,
INDIA
Pin: 133001

Email:
sales@japson.com
japsonambala@yahoo.com

Website:
www.japson.com
Phone:
+91-171-4006897

Rheostats, Continuous Constantine Type

Product Image



Description

Rheostat are used as series resistors or potentiometers. Open type slide wire type with a variety of resistance and current carrying capacity. Constantine wire is used as resistance. Contact provided on metal chrome plated slider-rod to give rapid and smooth adjustment. Three 4mm standard terminals are provided. One at each end of the wire and the third at one end of the slider-rod thus the Rheostat can be used as potentiometer also. Resistance in ohms and current carrying capacities are marked on it. The end support are made of bakelite.

Catoluge No	Particulars
JZ02860	Rheostats 10 ohms Continuous Constantine Type
JZ02861	Rheostats 20 ohms Continuous Constantine Type
JZ02862	Rheostats 30 ohms Continuous Constantine Type
JZ02863	Rheostats 50 ohms Continuous Constantine Type
JZ02864	Rheostats 100 ohms Continuous Constantine Type

A quality product from JAPSON ideal for use in School Laboratories in developing countries of Asia, Africa and South America.

Standard specifications for school laboratory use. Ideal mix of Quality and Economy. Other configurations and superior quality available for specific use or for developed countries.

Disclaimer

The Products details given on this page are indicative in nature and JAPSON reserves the right to change them without prior notice. Buyer is also requested to re-check the specifications and other features of product at the time of order as product development is a continuous process and minor modifications may be made to design based on latest availability, process and design.